

Front Panel Keys

Item	Description
[0] through [9]	Data entry – some keys have additional functions in some cases
[CALL]	Select Call functions – Voice Monitor, DSL Monitor, or Talk Pair
[CFG]	View and/or change configurations for System, CO, Location, User, Reference Pair, or retrieve ATV R/T information.
[CLR]	Terminates the current function and returns the unit to the <IDLE> screen
# [ENT]	Used to save data on some screens
[F1], [F2], [F3], and [F4]	Context screen keys – the function of the key is indicated by a label on the display above the key
[PWR]	Turn the power ON or OFF
[RCL]	View internally saved test results
[RMT]	Testing features using the ATV R/T
[TEST]	Select automatic or manual test functions
[TONE]	Select tone functions – ID Tone, Tagging, and End2End
Charge LED	Red – Indicates the internal battery is charging when on
Display	320 x 240 backlit LCD
Ext. Power LED	Green – Indicates an external power source is connected when on



Bottom Panel



Item	Description
25 Pair Connector	50 conductor (25 pair), male, Cinch-type connector used for bulk pair testing
AUX Connector	RJ 45 connector for the AUX cord – the AUX cord is used in Tagging and Caller ID automatic number retrieval
Ground Cord	Permanently connected cord that must be properly connected for all tests and measurements
PR 0 Connector	RJ 45 connector for the PR 0 cord – the PR 0 cord is used for single pair testing
Speaker	Speaker – speaker volume may be low if this area is blocked

## Function Quick Access

Function	Key Presses
AC Voltmeter	<IDLE> + [F2] – Press [7] for additional sensitivity and readings in dB
Assigned Number Retrieval, Caller ANAC	Automatic: [TEST] + UserA/UserB/ UserC + [F2] Setup Manual: [TEST] + [F2] Manual + select Number Retrieval (ANAC)
Assigned Number Retrieval, Caller ID	Automatic: [TEST] + User Test A/User Test B/ User Test C + [F2] Setup Manual: [TEST] + [Manual] + [F1] Next + select Number Retrieval (CID)
Automatic Test	[TEST] – Select one of the three standard test or the three User tests.
Automatic Test and Save Results	[TEST] – Select one of the six automatic tests and save at the end of the test. Only automatic test results can be saved.
Automatic Test Using PR0 Cord	[Test] + select any automatic test + [F4] PR0 Mode
Central Offices, Configure	[CFG] + [F2] CO – four CO configurations are available
Change Display Backlight	<IDLE> + Backlight use [4] Decrease or [6] Increase or [CFG] + [F1] System + [F3] Display
Change Display Contrast	<IDLE> + Contrast use [2] Increase or [8] Decrease or [CFG] + [F1] System + [F3] Display
Change Volume Settings	[3] V+ or [9] V- for function using the speaker or [CFG] + [F1] System + [F4] Volume
Charge ATV-25	Connect a 12VDC source to the Power connector on the left side of the ATV-25. The source may be a vehicle power cord, the provided charger adapter, or other suitable source. Note: The charger should not be used during noise measurements.
Connect to PC	Connect the USB connector on the left side of the ATV-25 to a USB cable connected to a PC running ATV Tools. No key presses are required.
Convert Resistance (Ohms) to Feet	<IDLE> + [F3] Ohms + [1] More + [F2] Distance – Press [F3] Gauge to change the wire gauge
DC Voltmeter	<IDLE> + [F1] DC Volts
Delete Test Results	[RCL] + select test result to delete + [F4] Delete
Idle Screen -- <IDLE>	[CLR] or [PWR] off + [PWR] on
Load Coil Detection	Automatic: [TEST] + UserA/UserB/ UserC + [F2] Setup Manual: [TEST] + [F2] Manual + select Load Coil Detection
Locations, Configure	[CFG] + [F3] Locations – 30 Location entries are available
Loop Current Test (POTS)	Automatic: [TEST] + UserA/UserB/ UserC + [F2] Setup Manual: [TEST] + [F2] Manual + select Loop Current
Loss, POTS	Automatic: [TEST] + UserA/UserB/ UserC + [F2] Setup Manual: [TEST] + [F2] Manual + select POTS Loss
Manual Test on a Single Pair Without saving the results.	[TEST] + [F2] Manual – select a test, select a pair, and start the test.
Monitor Data Line	[CALL] + [F2] DSL
Monitor Voice Line (Butt Set Mode)	[CALL] + [F1] Voice
Noise, POTS	Automatic: [TEST] + UserA/UserB/ UserC + [F2] Setup Manual: [TEST] + [F2] Manual + select POTS Noise
Noise, Vacant Pairs	Automatic: [TEST] + UserA/UserB/ UserC + [F2] Setup Manual: [TEST] + [F2] Manual + select Noise (Vacants)
Ohmmeter (Resistance)	<IDLE> + [F3] Ohms
Open Meter (Capacitive Distance)	<IDLE> + [F4] OpenMtr
Pair Tagging, ATV-25 to ATV R/T	[RMT] + select Groups + [F1] Start
Pair Tagging, ATV-25 to ATV-25	[TONE] + [F2] Tagging – This feature allows tagging between two or more ATV-25 s
Rapid Pair Automatic Test	[TEST] – Select Rapid
Recall Saved Test Results	<IDLE> + [RCL] + select the results to recall
Reference Pairs, Configure	[CFG] + [1] More + [F1] Ref Pair – four Reference Pair configurations are available
Remote Tone, ATV R/T	[RMT] + [F1] Start + [F2] RmtTone
Set Date/Time	[CFG] + [F1] System + [F3] DateTime
Set Test Limits	[Test] + select any automatic test + [F3] Limits
Special Circuit Id, T1, HDSL, xDSL	Automatic: [TEST] + UserA/UserB/ UserC + [F2] Setup Manual: [TEST] + [F2] Manual + select Special Ckt ID (DSL/T1)
Spectral Plot	Automatic: [TEST] + UserA/UserB/ UserC + [F2] Setup Manual: [TEST] + [F2] Manual + select + Spectral Plot
Talk/Wait Circuit	[CALL] + [F3] TalkPr, toggles the talk circuit on or off
Tone, Send ID Tone, 577Hz or 1004Hz	[TONE] + [F1] ID Tone
Users, Configure	[CFG] + [F4] User – four User configurations are available
Vacant Pair Automatic Test	[TEST] – Select Vacant
Working Pair Automatic Test	[TEST] – Select Working